


*Use this line art for your
advertising...*



Duck Pond Packing List

<u>DESCRIPTION</u>	<u>QUANTITY</u>
50 GALLON TUB	1
SUBMERSIBLE PUMP	1
STEEL BASE	1
SIGN POSTS	2
PLASTIC DUCKS	36
RUBBER DUCKS	2
STRIPED SKIRTING	1

Visit our website at:
www.twisterdisplay.com

TWISTER DISPLAY
P.O. BOX 2704 EAST LIVERPOOL, OH 43920
PHONE (330) 386-1270 FAX (330) 386-0418
ORDER DESK: (800) 637-3656
EMAIL sales@twisterdisplay.com

TWISTER DISPLAY
P.O. BOX 2704 EAST LIVERPOOL, OH 43920
PHONE (330) 386-1270 FAX (330) 386-0418
ORDER DESK: (800) 637-3656
EMAIL sales@twisterdisplay.com

Duck Pond

Assembly Instructions

1. Select a level area to operate game with plenty of room to allow for a line to form. Keep a safe distance between player and the electrical cord and power source.
2. Place the steel base on a firm, level area.
3. Place the tub on top of the base.
4. Attach the skirting to the tub.
5. Insert the sign posts on either side of the tub, and slip the sign board in place.
6. Put a rubber duck onto the tops of both posts.
7. When taking down the game, do not fold skirting wet. Always dry thoroughly first.
8. If storing outside, leave the tub upside-down, so that rainwater does not collect inside.

Replacement Parts List

Tub	\$185
Ducks (plastic)	\$1 each
Ducks (rubber)	\$3 each
Frame	\$225
Pump	\$75
Plug	\$9
Sign	\$100
Sign Post	\$10 each
Skirt	\$40

Duck Pond

Safety Instructions

1. Be sure to read the safety instructions included with the pump before use.
2. Before each use, inspect the power cord for any nicks or bad places in the insulation.
3. As always, use extreme caution when using electrical items near water.
4. The pump is supplied with a grounding conductor. To reduce the risk of electrical shock, be certain that it is connected to a properly grounded grounding type receptacle. **DO NOT REMOVE THE THIRD PRONG FROM THE PLUG.**
5. Do not use an extension cord.
6. Be sure that the power cords run behind the unit and do not pose a trip-hazard.
7. Be sure to continually mop up any water that is splashed onto the floor, to avoid any slip hazard.
8. Do not pull the pump out of the water by its cord when the pump is operating or connected to the power source.
9. **NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!**
10. **NEVER LEAVE THE TUB UNATTENDED WITH ANY AMOUNT OF WATER IN IT.**