

# The **BIG SPLASH**

## Set-Up & Safety Instructions




**1 800 637-3656**

**[www.twisterdisplay.com](http://www.twisterdisplay.com)**




# Parts List



**Tee Fitting**

**Quantity: 1**




**Corner Fitting**

**Quantity: 2**



**Four-Way Fitting:**

**Quantity: 2**



**Trigger Unit:**

**Quantity-1**



**36" Pipe: Quantity-4**



**44.5" Tapered Pipe: Quantity-3**




**41.5" Pipe: Quantity-5**



**Bucket Assembly:**


**Quantity-1**



**Target Cross Brace: Quantity-1**



**Collar: Quantity-1**




**Target Arm: Quantity-1**



**Target: Quantity-1**



**Sponge Balls:  
Quantity-12**




**Filler Tube Hook:  
Quantity-1**



**Filler Tube:  
Quantity-1**



**Filler Tube  
Clips:  
Quantity-3**



**Vinyl Canvas:  
Quantity-1**



**Slide the bucket assembly onto the trigger unit. Make sure that it is positioned so that the roller engages with the trigger hook.**




**Slide on the collar and tighten.**



**Slide on a corner fitting and tighten.**







(The cross brace will be slid up to meet the target arm hole, once the canvas is attached.)




Attach the garden hose to the connector/valve.

## Step 6

Insert filler tube hook and tighten.

## Step 7

Use the clips to route the filler tube along the frame to wherever you are going to run the garden hose.





## Step 8

Attach the canvas to the frame with the Velcro straps. (You may now need to slide the cross brace up to meet the hole for the target arm.)

## Step 9

Attach the garden hose to the connector/valve.



# ***Safety Instructions***

- ♦ ***Never use baseballs or hard balls. (Use only the balls provided.)***
- ♦ ***Set up on level ground.***
- ♦ ***Keep Big Splash staked and/or sandbagged for stability.***
- ♦ ***Keep Big Splash away from electricity.***
- ♦ ***Never stand under the bucket when in use.***
- ♦ ***Do not allow anyone to climb on or lean against the Big Splash.***
- ♦ ***Do not allow anyone to hit the target with their hand.***
- ♦ ***Take down the Big Splash if there is high wind or chance of lightening.***

**1 800 637-3656**

***www.twisterdisplay.com***