

~~*SPEED PITCH*~~

Safety Instructions

1. Be sure that there is plenty of clearance between the pitcher and spectators.
2. Do not allow the pitcher to be more than 10' in front of the unit.
3. **NEVER ALLOW SPECTATORS TO CROSS IN FRONT OF PITCHING AREA AT ANY TIME.** It is advised that this area be roped off.
4. Make sure that the netting is securely fastened to the framework so no balls can slip through.
5. Keep spectators clear from the sides and back of unit to prevent them from being struck by a deflected or errant throw.
6. **NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!**
7. Use caution when setting up or taking down the game. Once the bolts are loosened the sections of tubing can come apart and fall down causing injury.
8. Use only the soft baseballs included with the game.

TWISTER DISPLAY

P.O. BOX 2704 – EAST LIVERPOOL, OH 43920
PHONE (330) 386-1270 FAX (330) 386-0418
ORDER DESK: (800) 637-3656

EMAIL sales@twisterdisplay.com