

# 2 MINUTE DRILL



***Set-Up/Safety Instructions***

***[www.twisterdisplay.com](http://www.twisterdisplay.com)***

# 2 MINUTE DRILL



**A**

**46"**



**B**

**38"**



**C**

**38"**



**D**

**36"**




**E**

**36"**  
*(Hinged)*




**F**

**24"**




**Fitting #1**  
**(4-Way)**



**Fitting #2**  
**(4-Way**  
**with 1/2"**  
**Bolt)**



**Fitting #3**  
**(Coupler)**




**Fitting #4**  
**(Elbow)**  
**(Pre-attached**  
**to Pipe F)**

# 2 MINUTE DRILL

## *Packing List*

<b><i>Part</i></b>	<b><i>Quantity</i></b>
A Pipes	4
B Pipes	6
C Pipes	4
D Pipes	2
E Pipes (with hinge)	2
F Pipes	2
#1 Fittings	4
#2 Fittings	2
#3 Fittings	6
#4 Fittings	2
1/4" x 2 1/2" Hex Bolts	4
1/4" Lock Nuts	4
1/4" Flat Washers	4
3/8" x 3" Bolts	4
3/8" Lock Nuts	4
1/2" Lock Nuts	2
Backboard	1
Electronic Scorekeeper (W/4 Sensors)	1
Mini-Footballs	6
Ball Ramp	1
A/C Adaptor	1
Wheels	2





# 2 MINUTE DRILL


Attach both D pipes to the back of the backboard with the four 1/4" hex bolts.

Put a flat washer on each bolt and insert through the front of the backboard, and then the holes in the D pipes.

Attach both C pipes to the D pipes using two 3/8" x 3" hex bolts and lock nuts.




**Front**








# 2 MINUTE DRILL



# Assemble framework per illustrations below.



# 2 MINUTE DRILL





# 2 MINUTE DRILL



Loosen a coupler on either side of ramp  
in order to fold game.

**1 800 637 3656 ~ [www.twisterdisplay.com](http://www.twisterdisplay.com)**

# 2 MINUTE DRILL



## **SAFETY WARNING**



### **Safety Instructions**

Use only under adult supervision.

Do not allow anyone to climb on unit. The ball ramp and frame are not designed to support a person's weight.

Do not use in rain or in wet areas.

Be sure that there is plenty of clearance between the player and spectators.

Keep spectators clear from the sides and back of canvas to prevent them from being struck by a deflected or errant throw.

### **NEVER USE THE GAME IN STRONG WINDS OR LIGHTENING!!**

Use caution when setting up or taking down the game. The sections of tubing can come apart and fall down, causing injury.

Use only the balls included with the game. Do not use hard balls or other hard objects.



## **WARNING**



***Do not allow anyone to climb on unit.  
The ball ramp and frame are not  
designed to support a person's weight.***

***Do not use in rain or in wet areas.***